


LMC011A

LAYTON TRACTOR COMPANY

## ELECTRICAL SYSTEM - continued



LMC0118





ELECTRICAL SYSTEM

| ITEM | NOTES | PART NUMBER | QTY | DESCRIPTION               |
|------|-------|-------------|-----|---------------------------|
|      |       |             |     | <b>Electrical System</b>  |
| 1    |       | 588077      | 1   | Oil Gauge                 |
| 2    |       | 588057      | 1   | Fuel Gauge                |
| 3    |       | 588074      | 1   | Amp. Gauge                |
| 4    |       | 588028      | 1   | Hour Meter                |
| 5    |       | 587051      | 1   | Temp. Gauge               |
| 6    |       | 588095      | 1   | Switch, Main              |
| 7    |       | 587113      | 1   | Installation              |
| 8    |       | 587064      | 1   | Terminal Box              |
| 9    |       | G24-8327    | 4   | Bolt, 8-32 x 1 FHCS       |
| 10   |       | 588145      | 8   | Nut, 8-32                 |
| 11   |       | 587109      | 1   | Battery                   |
| 12   |       | 588144      | 2   | Bolt, 3/8-16 x 1-1/2 HHCS |
| 13   |       | 500012      | 2   | Nut, 3/8-16               |
| 14   |       | 500056      | 2   | Lockwasher, 3/8           |
| 15   |       | 587081      | 1   | Battery Top               |
| 16   |       | 7306        | 1   | Battery Cable, Neg.       |
| 17   |       | 7305        | 1   | Battery Cable, Pos.       |
| 18   |       | 588164      | 1   | Fuse, 50 amp              |